

STEP-BY-STEP



Pearls are always a mainstay in fashion circles. Add in a pop of color, such as the pink cubic zirconias in these earrings, for a fresh look.

Findings Used



536
Round 9-
Stone Top Plate



CZ-SYN
Round Lab Created
Pink Cubic Zirconias



28576
Pearl Cap
Dangle

Step-by-Step



1. Choose two opposite corners of the cluster plate and solder a jump ring to each.



2. Prepolish your cluster plate, and set the pink cubic zirconias.



3. Assemble the bishop hook and dangle component. Solder the jump rings closed. Give it a final polish.



4. Test your pearls for proper fit. Adjust the drill hole if necessary to allow space for adhesive. Use a pearl specific adhesive to bond pearl and dangle together. Let it dry.

Tools Used



26-4013

GRS

Graversmith
Pneumatic Power Tool



53-1200

Pearl Drill Set



47-3297

Gray Star
Rouge



34-2242

Foredom® Jewellers
Kit with H.20
Handpiece



16-6056

Stuller Select
Mounted Extra Soft
Bristle Brushes



26-6010

Devcon® Epoxy 330